


Pocket Lie & Loft Gauge

A machinist's protractor has fitting for measures lie and loft, sole angle and hosel bore exit. The jigs help position the club-head and protractor for each measurement to be made.




Can use!

▲ Measuring Loft Angle



▲ Measuring Lie Angle



▲ Measuring Bounce Angle