



Putter Shaft Bending Tool with Clamp

A great tool for altering the lie and loft on hosel-less putters fitted with either straight or double bend putter shafts.

The putter is mounted in the fixture and secured. The sheave is then adjusted height wise to guide the shaft.

The shaft is bent by grasping at it with both hands and pulling progressively in the direction of the adjustment. Works with right and left handed putters.

